



## **INSTALLATION INSTRUCTIONS FOR CARBON SHIFT PADDLES FERRARI F360 COUPE, SPYDER, CHALLENGE, & CHALLENGE STRADALE**

Thank you for choosing to purchase a Carbonio product. Please take the time to fully read over these instructions before attempting to install the kit. This will greatly speed up the installation process and minimize any difficulties you may encounter.

### **Tools Required:**

- Phillips (star) screwdriver

### **Kit includes:**

2 – Carbon fiber shift paddles

**Step 1:** Insert the key in the ignition and turn it unlocking the steering and allowing the steering wheel to turn freely.

**Step 2:** Turn the steering wheel until the screws that hold the factory shift paddles in place are exposed. Using a Philips head screwdriver, remove the 2 screws that hold the paddle in place.

**Note: Each screw has a beveled washer. Make sure this washer stays with the screw as it will be used in the install of the carbon paddles.**

**Step 3:** In the reverse of Step 2, install the Carbonio carbon fiber paddle in the place of the original paddle. Be sure to use the beveled washers that came off of the factory paddles and ensure that the screws are tight.

**TIP: Be sure to start both screws before tightening them down. This will ensure that the paddles go on straight.**

**Step 4:** Repeat Steps 2 and 3 for the other paddle

**Note: The added convenience of the Challenge paddles may require a compromise to some owners. The very long up-shift paddle may interfere with the windshield spray stalk causing an up-shift when spraying the windshield clean. To avoid this it is necessary to put the stalk in the wiper on position before spraying the glass.**

## **LABOUR ESTIMATE GUIDE**

**10 Minutes**